



Applicational Mounting Chart Guide

Please verify mirror mount first with photos provided. Mount replacement varies between trim models and packages.

Make	Model	Year	Mount Required	Installation notes
Audi	A3 hatchback	2000-2008	#3	
	A3 hatchback	2008-2014	#3 or #22	
	A4	1994-2008	#3	
	A4	2008-2014	#3 or #22	
	A5	2007-2014	#3 or #22	
	A6	1994-2008	#3	
	A6	2008-2014	#3 or #22	
	TT	1998-2014	#3 or #22	
BMW	Fits various models with Twist Lock Mount		#35	
Chevrolet / Buick / GMC	Compatible With Most		Universal Mount	
Chrysler	Older models not listed		Universal Mount	Uconnect can be moved to headliner by professional installation only.
	200	2012-2014	Universal or #35	
	300	2006-2011 Only	Universal Mount	
	300	2012-2014	#35	
	PT Cruiser	2001-2011 Only	Universal Mount	
	Sebring	2007-2011	Universal Mount	
	Town & Country	2001-2014	Universal Mount	

Make

Model

Year

Mount Required

Installation notes

Make	Model	Year	Mount Required	Installation notes
Dodge / Ram	Older models not listed		Universal Mount	
	Avenger	2007-2014	Universal or #35	
	Caliber	2008-2011 Only	Universal or #35	
	Caravan	2001-2014	Universal Mount	
	Charger	2008-2011 Only	Universal Mount	
	Charger	2012-2014	Universal or #35	
	Dakota	2007-2011 Only	Universal Mount	
	Dart	2013	Universal or #35	
	Durango	2013-2014	Universal or #35	
	Journey	2009-2011	Universal Mount	
	Journey	2012-2014	Universal or #35	
	Nitro	2009-2011	Universal Mount	
	Ram	2009-2012	Universal Mount	
	Ram	2013-2014	#35	
ProMaster	2014	#35		
Fiat	Compatible With Most		#15	
Ford	Older models not listed		Universal Mount	
	Cmax	2013-2014	Universal or #35	
	Edge	2007-2014	Universal or #35	
	Escape	2007-2014	Universal or #35	
	E-Series	1997-2013	Universal Mount	
	Expedition	1997-2014	Universal Mount	
	Explorer	1998-2014	Universal or #35	
	F-150	2004-2014	Universal Mount	
	Fiesta	2011-2014	Universal or #35	
	Flex	2008-2014	Universal or #35	
	Focus	2007-2014	Universal or #35	
	Fusion	2006-2014	Universal or #35	
	Mustang	2000-2014	Universal Mount	
	Ranger	1995-2011	Universal Mount	
	Super Duty	2008-2014	Universal Mount	
Taurus	2007-2014	Universal or #35		
Transit	2013	Universal or #35		

Please verify mirror mount first with photos provided. Mount replacement varies between trim models and packages.

Make	Model	Year	Mount Required	Installation notes
Honda	Accord	2009-2012 Only	Universal or #2	Mirror may hit headliner, please check clearance and use #14 extended mount if needed
	Civic	2009-2014	Universal or #2	
	Crosstour	2010-2013	Universal or #2	
	CR-V	2009-2013	Universal or #14	
	CR-Z	2012	Universal or #2	
	Element	2007-2011	Universal or #2	
	Fit	2007-2013	Universal or #2	
	Insight	2011-2013	Universal or #2	
	Odyssey	2007-2012	Universal or #2	
	Pilot	2008-2013	Universal or #14	
	Ridgeline	2007-2012	Universal or #2	
	Older models that are discontinued		Most use Universal mount	
Hyundai	Accent	2008-2013	Universal or #8	To keep models with HomeLink, please purchase HomeLink Kit to be placed in headliner or visor. Sold separately. Blue link can be moved to headliner by professional installation only.
	Elantra	2008-2013	Universal or #8	
	Elantra (touring)	2011	Universal or #8	
	Sonata	2011-2014	Universal or #8	
	Azera	2008-2013	Universal or #8	
	Genesis	2010-2013	Universal or #8	
	Tucson	2008-2013	Universal or #8	
	Santa Fe	2008-2012	Universal or #8	
	Veraacruz	2008-2012	Universal or #8	
Velostor	2011-2014	Universal or #8		
Jeep	Compatible With Most		Universal Mount	Uconnect can be moved to headliner by professional installation only.

Make	Model	Year	Mount Required	Installation notes
Kia	Forte	2011	Universal or #8	
	Forte (SEDAN)	2012-2014	Universal or #8	
	Optima	2008-2013	Universal or #8	
	Rio	2008-2013	Universal or #8	
	Rondo	2008-2011	Universal or #8	
	Sedona	2007-2013	Universal or #8	
	Sorento	2007-2014	Universal or #8	
	Soul	2009-2014	Universal or #8	
Sportage	2008-2013	Universal or #8		
Lexus	CT200h	2011 - 2013	Universal Mount	To keep models with HomeLink, please purchase HomeLink Kit to be placed in headliner or visor. Professional installation required. (Sold separately). Specialty mount may be needed for convertibles.
	CT200F	2011 - 2013	Universal Mount	
	GS 350	2011 - 2013	Universal Mount	
	GS 350F	2011 - 2013	Universal Mount	
	GS 450H	2011 - 2013	Universal Mount	
	GX 460	2011 - 2013	Universal Mount	
	IS 250	2010-2014	Universal Mount	
	IS 250F	2010-2014	Universal Mount	
	IS 350	2010-2014	Universal Mount	
	IS 350F	2010-2014	Universal Mount	
	LS 460	2011-2014	Universal Mount	
	LS 460F	2011-2014	Universal Mount	
	LS 600h	2011-2014	Universal Mount	
LX 570	2011-2012	Universal Mount		
Land Rover	Most Models with new twist lock mount		#35	Models equipped with rain sensors or forward collision, no mounting solution available to keep those features.

Make	Model	Year	Mount Required	Installation notes
Mazda	2	2011-2013	Universal Mount	To keep models with HomeLink, please purchase HomeLink Kit to be placed in headliner or visor. Professional installation required. (Sold separately)
	3	2008-2014	Universal Mount	
	5	2007-2013	Universal Mount	
	6	2007-2014	Universal Mount	
	CX-5	2012-2014	Universal Mount	
	CX-7	2008-2013	Universal Mount	
	CX-9	2008-2013	Universal Mount	
	MX-5	2006-2013	Universal Mount	
	RX 8	2004-2012	Universal Mount	
	Tribute	2007-2011	Universal Mount	
Mercedes	Some models may need speciality mount		#15 or #22 or #22N	Older windshield mounted factory mirrors need #15. Headliner mounted factory mirrors need professional installation using one of our speciality mounts, #19.
	Sprinter Van		#SpinterVan-SmartCar adaptor	
Mini Cooper	All Models		#3 or #17 Specialty mount	Mini Coopers with no headliner console typically use #3 mount but you must use the factory clip to replace the #3 clip. Mini Coopers with a headliner console need #17. The unlock/lock sensor may need to be relocated into headliner

Make	Model	Year	Mount Required	Installation notes
------	-------	------	----------------	--------------------

Mitsubishi	Eclipse	2011-2013	Universal or #8	To keep models with HomeLink, please purchase HomeLink Kit to be placed in headliner or visor. Professional installation required. (Sold separately)
	Galant	2011-2013	Universal or #8	
	Evolution X	2012	Universal or #8	
	Mi-EV	2012-2013	Universal or #8	
	Outlander	2007-2013	Universal or #8	
	Lancer Wagon	2013	Universal or #8	
	Older models that are discontinued		Most use Universal mount	

Nissan	350-370z	2003-2014	Universal Mount	To keep models with HomeLink, please purchase HomeLink Kit to be placed in headliner or visor. Professional installation required. (Sold separately)
	Altima	2008-2012	Universal Mount	
	Armada	2007-2013	Universal Mount	
	Frontier	2008-2013	Universal Mount	
	GT-R	2011-2013	Universal Mount	
	Juke	2011-2013	Universal Mount	
	Leaf	2012-2013	Universal Mount	
	Maxima	2009-2013	Universal Mount	
	Murano	2007-2013	Universal Mount	
	NV200	2012-2013	Universal Mount	
	Pathfinder	2008-2014	Universal Mount	
	Quest	2004-2013	Universal Mount	
	Rogue	2011-2013	Universal Mount	
	Sentra	2007-2013	Universal Mount	
	Titan	2007-2013	Universal Mount	
Versa	2011-2014	Universal Mount		
Xterra	2008-2013	Universal Mount		

SmartCar	All models		#14 and #sprinterVan-SmartCar Adaptor	
-----------------	------------	--	---------------------------------------	--

Make	Model	Year	Mount Required	Installation notes
------	-------	------	----------------	--------------------

Subaru	Forester	2007-2014	Universal or #2	To keep models with HomeLink, please purchase HomeLink Kit to be placed in headliner or visor. Professional installation required. (Sold separately)
	BR-Z	2013-2014	Universal or #2	
	Impreza	2007-2013	Universal or #2	
	Legacy	2008-2014	Universal or #2	
	Outback	2008-2014	Universal or #2	
	WRX	2008-2013	Universal or #2	
	XV Crosstrek	2013	Universal or #2	
	Tribeca	2008-2013	Universal or #2	

Suzuki	Equator	2011-2013	Universal Mount	
	Kizashi	2011-2013	Universal Mount	
	SX4	2011-2013	Universal Mount	

Toyota	4Runner	2001-2014	Universal Mount	To keep models with HomeLink, please purchase HomeLink Kit to be placed in headliner or visor. Professional installation required. (Sold separately). If factory mirror has internal mic, relocate to headliner with professional assistance.
	Avalon	2013-2014	Universal Mount	
	Camry	2001-2014	Universal Mount	
	Corolla	2001-2014	Universal Mount	
	Highlander	2003-2014	Universal Mount	
	Land Cruiser	2013	Universal Mount	
	Matrix	2003-2013	Universal Mount	
	Prius	2005-2014	Universal Mount	
	Prius V	2012-2014	Universal Mount	
	RAV4	2001-2014	Universal Mount	
	Sequoia	2013	Universal Mount	
	Sienna	2012-2014	Universal Mount	
	Tacoma	2001-2014	Universal Mount	
	Tundra	2003-2014	Universal Mount	
	Venza	2009-2013	Universal Mount	
Yaris	2005-2014	Universal Mount		

Make	Model	Year	Mount Required	Installation notes
------	-------	------	----------------	--------------------

Toyota / Scion	FR-S	2013-2014	Universal Mount	
	iQ	2012-2014	Universal Mount	
	TC	2007-2014	Universal Mount	
	Matrix	2003-2013	Universal Mount	
	xD	2007-2014	Universal Mount	
	xB	2007-2014	Universal Mount	

Volkswagen	Beetle	2012-2014	#3	
	CC	2012-2014	#3	
	EOS	2007-2010	#3	
	GTI/Golf	2007-2013	#3	
	Jetta	2003-2014	#3	
	Passat	2005-2014	#3	
	Routan	2009-2013	Universal or #3	
	Tiguan	2009-2010	#3	
	Tourag	2007-2010	#3	



Applicational Mounting Chart Guide

<p>1</p> <p>Universal, fits most domestic vehicles</p>	<p>2</p> <p>Honda, Subaru</p>	<p>3</p> <p>V.W., older Audis</p>	<p>5</p> <p>Geely, Brilliance</p>	<p>6</p> <p>Chery, Brilliance</p>	<p>7</p> <p>Hyundai, Kia, MG</p>	<p>8</p> <p>Hyundai, Kia with base</p>	<p>9</p> <p>Speciality Mount</p>
<p>14</p> <p>Extended #1 mount for low ceiling</p>	<p>15</p> <p>Fiat, older Mbenz</p>	<p>17</p> <p>Speciality Mount</p>	<p>18</p> <p>Speciality Mount</p>	<p>19</p> <p>Speciality Mount</p>	<p>20</p> <p>Some Subaru</p>	<p>21</p> <p>Older Hondas</p>	<p>22</p> <p>Audi 3 prong, Mbenz</p>
<p>22n</p> <p>Audi 4 prong, Mbenz</p>	<p>35</p> <p>BMW, new Chrysler and Dodge</p>	<p>47</p> <p>Some Chevrolet, Mitzubishi</p>	<p>SV</p> <p>Sprinter Van, SmartCar plus #14</p>				